


RWG500 SERVICE PARTS LIST



WGT405310

**Valid as of
Feb 1st, 2010**

SATO CORPORATION . TOKYO. JAPAN




DESCRIPTION BASE FRAME ASSY


RWG500 SERVICE PARTS LIST


AssyName BASE FRAME ASSY


	First_Code	Description	Standard
1	R05581001	BASE FRAME ASSY	
2	PT6680100	CASE LEG	




DESCRIPTION CENTER FRAME ASSY(1)











DESCRIPTION
CENTER FRAME ASSY(5)



DESCRIPTION
CENTER FRAME ASSY(6)



DESCRIPTION
CENTER FRAME ASSY(7)

RWG500 SERVICE PARTS LIST


AssyName CENTER FRAME ASSY

	First_Code	Description	Standard
4	R05582001	CENTER FRAME ASSY	
5	MD4400822	PAN HEAD SCREW+SW+WL	
6	PT6700200	COLOR LEG	
7	MD3300822	PAN HEAD SCREW+SW+WS	
8	P13558000	KB PANEL SHEET	
10	P12761000	REWIND SHAFT	
11	P00097100	REWIND CORE	
12	MD3301022	PAN HEAD SCREW+SW+WS	
13	PT1112080	BALL BEARING	
14	P14049000	STOPPER PLATE(B)	
15	P13284001	REWIND CORE COLLER	
16	P13888001	COLLER GUIDE	
17	PE1761320	STOPPER PLATE (A)	
18	PE1760820	GUIDE BOSS	
19	MH0301221	PAN HEAD P TIGHT SCREW	
21	P12770001	SHAFT(ARM1)	
22	P12768001	SHAFT(ARM)	
23	PB3010110	GUIDE ROLLER	
24	PT2107050	BUSH	
25	P11150000	SCREW CAP	
26	ND0060030	E RING	
32	R05951000	GUIDE CORE(3INCH)ASSY	
33	PR7693600	GUIDE CORE(3INCH)SET	
34	P13285000	3INCH CORE COLLAR	
35	MD3301022	PAN HEAD SCREW+SW+WS	
37	P04532000	BUSHING	
38	MA0201022	PAN HEAD SCREW	
40	P13282000	PULLY(60)	
41	P14518000	TORQUE LIMITER	
43	P12750001	ARM	
44	MT1400722	HEX NUT	
45	MA0201022	PAN HEAD SCREW	
47	P13286001	ARM GUIDE	
48	MD4301422	PAN HEAD SCREW+SW+WL	
61	ND0040030	E SNAP RING	
62	ND0050030	E SNAP RING	
63	PT1112060	BALL SUPPORTER	
64	PC0730100	SPRING (BACK)	
65	P13140000	SLIT	
66	P13943000	WINDING TYPE SPACER	
67	MD4300822	PAN HEAD SCREW+SW+WL	
69	P12771001	SHAFT(GUIDE)	
70	PE1760920	BOSS(A)	
71	PT2016010	DRY METAL	

RWG500 SERVICE PARTS LIST

AssyName CENTER FRAME ASSY


	First_Code	Description	Standard
72	ND3160024	C-SNAP RING	
73	MD4400822	PAN HEAD SCREW+SW+WL	
74	P14339000	CAP(ROLL)	
75	P14340000	CAP(REWIND)	
77	P08439000	TIMING BELT	
78	P13296000	PLATE GUIDE	
79	MA0301222	PAN HEAD SCREW	
80	P13942000	WINDING TYPE SPACER	
82	K00113000	STEPPING MOTER	
83	P12752000	MOTOR PLATE	
84	MD4400822	PAN HEAD SCREW+SW+WL	
85	P14637000	MOTER PULLEY(16)L12	
86	MJ1400524	HEX W-POINT SCREW	
92	P13288000	SHAFT(GUIDE1)	
93	P13290000	GUIDE BRACKET TOP	
94	P13291000	GUIDE BRACKET UNDER	
95	M16220000	HEX UPSET SCREW	
96	P11150000	SCREW CAP	
97	MA2400824	BIND HEAD SCREW	
135	P13287001	COVER	
136	MA2400824	BIND HEAD SCREW	
137	PE6740300	DIP SW COVER	
139	Q01127000	STICKER(ROUTE)	



RWG500 SERVICE PARTS LIST

AssyName CONT PWB ASSY


	First_Code	Description	Standard
99	P12772000	BOARD(CONNECTOR)	
100	M16220000	HEX UPSET SCREW	
101	NB2040022	TOOTHED LOCK WASHER	
102	R05902000	POWER SWITCH ASSY	
103	R06012000	Adapter connector ASSY	
104	MA0301222	PAN HEAD SCREW	
105	MD4300822	PAN HEAD SCREW+SW+WL	
106	JG900411A	DUST CAP	
107	P14083000	DUST CAP	
110	R05891000	CONT PWB ASSY	
111	PT9800800	SPACER	
112	MD4300822	PAN HEAD SCREW+SW+WL	



RWG500 SERVICE PARTS LIST

AssyName BOARD ASSY

	First_Code	Description	Standard
122	R06305000	OP PWB ASSY	
123	R05893000	OP PWB ASSY	
124	PT9800800	SPACER	
125	MD4300822	PAN HEAD SCREW+SW+WL	
126	R05905000	OP CABLE ASSY	
128	MA1300622	FLAT HEAD SCREW	
129	MD4300822	PAN HEAD SCREW+SW+WL	




DESCRIPTION
OP HARNESS ASSY


RWG500 SERVICE PARTS LIST

AssyName OP. HARNESS ASSY

	First_Code	Description	Standard
131	R05903000	SENER HARNESS ASSY	
132	MD3301022	PAN HEAD SCREW+SW+WS	
133	JG100011A	TIE WRAP	




DESCRIPTION
JOINT SA(1)



RWG500 SERVICE PARTS LIST

AssyName JOINT SA

	First_Code	Description	Standard
2	R05984000	JOINT SA	
3	P13292001	JOINT Pr	
4	P13295001	JOINT(Pro)	
5	MD4400622	PAN HEAD SCREW+SW+WL	
6	R06072000	FG ASSY	
7	R05906000	EXT POWER CABLE	
8	PC3690700	CLIP	
10	Q01450000	CARTON BOX(PR)	
11	R08475000	CUSHION SET(S)	
13	QB1680000	PACKING SEAT	
15	Q01160000	RWG500 Instruction manual	
16	Q01170000	RWG500 Quick Guide	




RWG500 SERVICE PARTS LIST

AssyName 6INCH EXIENTION KIT

	First_Code	Description	Standard
2	WWGT05970	6INCH ATTCHMENT ASSY	
3	P13872000	SHAFT(ROLLER6)	
4	P13874000	SHAFT(REWIND6)	
5	P13875000	REWIND CORE6	
6	PE4080100	PAPER GUIDE	
7	PT2016010	DRY METAL	
10	R05552000	PACKING SET	
11	Q01059000	CARTON CASE	
12	Q01060000	CUSHION	
13	Q00126000	AIR PACKING(500*500)	
14	Q01523000	PAD	

Option



DESCRIPTION
POWER SUPPLY

RWG500 SERVICE PARTS LIST

AssyName POWER SUPPLY

	First_Code	Description	Standard	Note
3	JH000441A	AC CABLE		
5	K00550302	AC ADAPTER-LF SATO LOGO CT4i RWG500		SEG2015.12.09: Changed from KA600081A SEG 12th June 2020: Changed from K00389000
6	R21128000	CONVERTER CABLE		

