



## LOADING INSTRUCTIONS

1. Lift transparent cover and place roll of labels into the machine.
2. Slide the release button (**A**) which allows the platen assembly (**D**) to drop down.
3. Feed end of roll of labels down above the platen assembly (**D**), and back into the platen assembly (an arrow indicates the appropriate slot).
4. Pull operating lever (**C**) a few times to feed roll through the machine.
5. Hold the end of the roll towards the operating lever and close the platen assembly (**D**).